

Uses

- For the pre-touch-up prior to filling scratches and holes with König fillers.
- For the covering touch-up by brush on wood, plastic and stone surfaces.
- To obtain basic shades and to restore the grain pattern.
- For the dyeing of Rex Lith wood and transparent.
- Recommended for both indoor and outdoor use.

Note: Limited use on stone, dependent on the strain factor.

Characteristics

- Pigmented covering lacquer based on acrylic.
- Dries rapidly.
- High opacity.
- Can be lacquered with any König Touch-Up and Aerosol lacquer.
- Good adhesion to many lacquer, plastic and metal surfaces (not to Soft-PVC).
- Good lightfastness and weather-resistance (adequate coat thickness required!).
- Limited PVC-resistance (window and door gaskets).
- Dried colours on the mixing palette can be dissolved and intermixed (also with Brush Pen Clear Lacquer).

Application

Shake pen well before use – approx. 20 seconds. Mixing balls must be audible. Take off cap. Hold pen with tip pointing upwards and de-aerate pen by pressing on area marked 'PRESS' (pressure adjustment is audible). Now hold pen with tip pointing downwards over a small wooden board, chip, tissue or cotton cloth and slowly press marked area until colour drips on the base. Stir colour lacquer drop on the base with the brush tip to achieve an optimum spreading of the liquid medium in the brush tip. Do not touch up too wet – especially when applying fine lines. When brush has dried up, either re-pump lacquer or dampen brush tip with Cellulose Thinner. Replace cap after use. Surfaces to be treated have to be free from dust, grease and silicone.

Recommendation: If brush pen is not being used for a longer time, clean tip with Cellulose Thinner.

Specifications

Dust-dry:	after approx. 1-2 minutes.
Touch-dry:	after approx. 2-5 minutes (dependent on room temperature and coat thickness).
Lightfastness:	good.
Weather resistance:	good.
Shelf life:	at least 2 years (stored at room temperature, in original unopened container)

Safety Precautions

- Highly inflammable.
- Irritant.
- Keep away from sources of ignition. – No smoking.
- Do not breathe vapour.
- Use in well-ventilated areas, only.
- Keep out of reach of children.

Extract of wordings of the law. For further information please see label and Material Safety Data Sheet.

Disposal


- Do not allow product to enter drains or watercourses.
- Pen to be added to the household waste, only when completely emptied and dried-out.
- Material leftovers to be disposed of according to the disposal key AVV 080111 – *waste paint and varnish containing organic solvents or other dangerous substances.*
- For additional information, consult the Material Safety Data Sheet for this product or ask your local waste industry office.

Available

Assortment of 5
Assortment of 10
Standard and special colour shades (S.A.)
Spare tips (order no. EB2889)

*Further information and Material Safety Data Sheet on the internet at
www.Pinsel-Fix.info*

Although reasonable care has been taken in the preparation of this document, we extend no warranties and make no representations as to the accuracy or completeness of the information contained herein, and assume no responsibility regarding the suitability of this information for the user's intended purposes or for the consequences of its use. Each individual should make a determination as to the suitability of the information for his or her particular purpose(s).

**Heinrich König & Co. KG**

An der Rosenhelle 5 • D-61138 Niederdorfelden
Phone: 0 61 01 - 53 60 0 • Fax: 0 61 01 - 53 60 11
E-mail: info@heinrich-koenig.de

issue 03/07